

Complemented Instruction for eStore V1.26 USB 3.5"Hard Disk Mobile Case Installation

Please note that the 3 short words below show up on this instruction representing the device with the specifications on the right side.(Notice: V1.26 upgrade only for V1.23 or V1.24,V1.25)

eStore: eStore host

USB HD: USB Mobile Hard Disk

System Disk: The Disk built-in DOM(Disk on Module) for version V1.26

1. Switch on the power of the USB HD and wait for 10 seconds or more. Then connect the USB connector to the eStore before the power of the eStore has been turned on. The light indicator of the eStore will change from orange to green simultaneously with a sound. Meanwhile, the management platform of the eStore can be accessed via <http://192.168.15.1:8080/admin.html/> when the second sound comes out. Normally the light indicator of the USB HD will be flashing continuously between the first and the second sound °
2. If the light indicator of the USB HD did not flash, please switch off the eStore by pressing and holding the button of power for about 10 seconds until the green light change to orange light. Then turn off the USB HD and disconnect the USB connector before repeat the same steps on point 1. Please do not connect or disconnect the USB HD when the eStore is on, or cut off the power of the USB HD via this way.
3. When the power is cut accidentally and then recover later on, the eStore will not like the USB HD re-starting automatically but show the orange light on the button. Please turn off the USB HD and disconnect the USB connector, same as the steps on point 2., then repeat the same steps on point 1.
4. After the USB HD plug in and is installed successfully, please enter the back-end managerial interface of the eStore to check the storage of your email box prior to start keying in any data. All installations are successful if the Data Disk appears on the screen. (Only the System Disk will appear if the USB HD has not installed yet.) If not, then repeat the same steps on point 1 and check if there is any problem with the USB HD.
5. The eStore supports IDE hard disks up to 300G. Don't partition nor format a new brought hard disk. Just connect it to the USB HD. For a used hard disk with partitions and data inside, please remove the partitions and format it before connecting to the USB HD.
6. In case the USB HD is connected when the System Disk is full or it has been used for a period of time only have System Disk, please backup the web pages to your personal computer. Secondly recover and clean up all items in the shopping carts. Thirdly down load all emails and

delete the email account, and copy the internet hard disk. Finally plug in the USB HD and recover all data after the above steps have been completed.

1. How to backup data:

Log on <ftp://username:password@192.168.15.1/../../cpbackup> After connecting successfully, please backup all data to your personal computer prior to delete web pages (in HTML format).

2. If the HTML files cannot be deleted, it means the account (or user name) of the HTML files is not the same as current account.

7. If the USB HDD is not our products, please confirm if the chip is Cypress CY7C68300(A)-56PVC (or named AT2 (AT2 Plus)). And hard disk must be desk type at 3.5 inches IDE interface.

8. Please download an upgrade version from a near end before proceeding upgrade when the upgrade system is needed. Don't upgrade the eStore system via internet. The eStore will generate 2 short-sounds continuously after system upgrade, reset or the shopping carts being recovered and clean up. When the 3th long-sound comes up, the system will be connected and entered in about 50 seconds. If the 3th sound did not happen, please shutdown the eStore and refer to the steps on point 1 and 2 to proceed.

9. After system being upgraded successfully, please active the Backup function to backup all the data of web pages. Please do not use the Restore function if you have already backup the data of web pages from a previous version system.